A

Accessories and Modifications.... 164
Accessories..... 164
Additional Safety Information.. 165
Modifications..... 165
ACCESSORY (Ignition Key Position)..... 72
Accessory Power Socket..... 102
Adding
Automatic Transmission Fluid.....221, 222
Brake Fluid..... 224
Clutch Fluid..... 225
Engine Coolant..... 213
Engine Oil..... 208
Manual Transmission Fluid 223
Power Steering Fluid..... 225
Windshield Washer Fluid..... 220
Additional Information About Your Seat Belts..... 40
Lap/Shoulder Belts..... 40
Seat Belt Maintenance..... 41
Seat Belt System Components... 40
Additional Information About Your SRS.....42
Additional Safety Precautions.... 45
How Your Airbags Work..... 42
How Your SRS Indicator Light Works..... 44
SRS Components..... 42
Additives, Engine Oil..... 210
Adjustments
Mirrors..... 95
Head Restraints..... 88
Seats..... 84
Steering Wheel..... 65
Airbag (SRS)..... 9
Air Cleaner Element..... 226
Air Conditioning..... 106
Maintenance..... 238
Usage..... 106
Air Conditioning Filter..... 239
Air Pressure, Tires..... 241
Alcohol in Gasoline..... 304
Antifreeze..... 213
Anti-lock Brakes (ABS)
Description..... 182
Indicator Light..... 53, 183
Operation..... 182
Anti-theft Steering Column Lock .. 71
Appearance Care..... 261
Audio System..... 121, 133
Automatic Speed Control..... 66
Automatic Transmission..... 174
Capacity, Fluid..... 298
Checking Fluid Level..... 221, 222
Shifting..... 174
Shift Lever Position Indicator.. 175
Shift Lever Positions..... 175
Shift Lock Release..... 178

B

Battery
Charging System Light..... 52, 284
Jump Starting..... 278
Maintenance..... 233
Specifications..... 299
Before Driving..... 155
Belts, Seat..... 8
Beverage Holder..... 100
Body Repair..... 267

CONTINUED

Index

Brakes
Anti-lock System (ABS)..... 182
Break-in, New Linings 156
Fluid..... 224
Light, Burned-out..... 251
Parking..... 97
System Indicator..... 52
Wear Indicators..... 181
Brakes, ABS
Description..... 182
Operation..... 182
System Indicator..... 53, 183
Braking System..... 181
Break-in, New Car..... 156
Brightness Control, Instruments... 61
Brights, Headlights..... 60
Bulb Replacement
Back-up Lights..... 255
Brake Lights..... 254
Ceiling Light..... 257
Courtesy Light..... 258
Front Parking Lights..... 253
Front Side Marker Lights..... 252
Headlights..... 251
High-mount Brake Light..... 256
License Plate Lights..... 256
Specifications..... 299
Spotlight..... 258
Trunk Light..... 259
Turn Signal Lights..... 252
Bulbs, Halogen..... 251

C

Cables, Jump Starting With..... 279
Capacities Chart..... 298
Carbon Monoxide Hazard..... 46
Carrying, Cargo..... 165
Cassette Player
Care..... 150
Operation..... 126, 147
CAUTION, Explanation of..... ii
CD Changer..... 129, 143
CD Player..... 141
Certification Label..... 296
Chains..... 246
Change Oil
How to..... 210
When to..... 198
Changing a Flat Tire..... 271
Changing Engine Coolant..... 213
Charging System Indicator... 52, 284
Checking
Automatic Transmission Fluid.....221
Battery Condition..... 233
Brake Fluid..... 224
Clutch Fluid..... 225
Drive Belts..... 239
Engine Coolant..... 162
Engine Oil..... 160
Fuses.....289
Manual Transmission Fluid 223
Power Steering Fluid..... 225
Checklist, Before Driving..... 170
Cleaner, Air..... 226
Cleaning
Aluminum Wheels..... 263
Carpeting..... 264
Exterior..... 262
Fabric..... 264
Interior..... 264
Seat Belts..... 265
Vinyl.....264
Window..... 265
Climate Control System..... 113
Clock, Setting the 98
Clutch Fluid..... 225

CO in the Exhaust..... 306
Coin Box..... 99
Cold Weather, Starting in..... 172
Compact Spare..... 270
Console Compartment..... 99
Consumer Information*..... 310
Controls, Instruments and..... 49
Coolant
Adding..... 213
Checking..... 162
Proper Solution..... 213
Temperature Gauge..... 57
Corrosion Protection..... 266
Crankcase Emissions Control System..... 306
Cruise Control Operation..... 66
Customer Relations Office..... 310

D

DANGER, Explanation of..... ii
Dashboard..... 50
Daytime Running Lights..... 61
Dead Battery, What to Do..... 278
Defects, Reporting Safety..... 314
DEXRON® III Automatic Transmission Fluid..... 221
Dimensions..... 298
Dimming the Headlights..... 60
Dipstick
Automatic Transmission ..221, 222
Engine Oil..... 160
Directional Signals..... 62
Disabled, Towing Your Car If..... 293
Disc Brake Wear Indicators..... 181
Disposal of Used Oil..... 212
Doors
Locking and Unlocking..... 72
Power Door Locks..... 72
DOT Tire Quality Grading..... 302
Downshifting, 5-speed Manual Transmission..... 172
Drive Belts..... 239
Driver and Passenger Safety..... 5
Driving..... 169
Economy..... 163
In Bad Weather..... 184
In Foreign Countries..... 305

E

Economy, Fuel..... 163
Emergencies on the Road..... 269
Battery, Jump Starting..... 278
Brake System Indicator..... 286
Changing a Flat Tire..... 271
Charging System Indicator 284
Checking the Fuses..... 289
Low Oil Pressure Indicator..... 283
Malfunction Indicator Lamp..... 285
Manually Closing Moonroof..... 287
Overheated Engine..... 281
Emergency Brake..... 97
Emergency Flashers..... 64
Emergency Towing..... 293
Emissions Controls..... 306
Engine
Belts..... 239
Coolant Temperature Gauge 57
Malfunction Indicator Lamp..... 53, 285
Oil Pressure Indicator..... 52, 283
Oil, What Kind to Use..... 208
Overheating..... 281
Specifications..... 299

CONTINUED

Index

Ethanol in Gasoline 304
Evaporative Emissions Controls.. 306
Exhaust Fumes..... 46
Expectant Mothers, Use of Seat Belts by..... 17
Exterior, Cleaning the..... 262

F

Fabric, Cleaning..... 264
Fan, Interior..... 106
Features, Comfort and Convenience..... 105
Filling the Fuel Tank..... 156
Filter
Air Conditioning..... 239
Oil..... 210
First Gear, Shifting..... 177
5-speed Manual Transmission Checking Fluid Level..... 223
5-speed Manual Transmission Shifting the..... 172
Flashers, Hazard Warning..... 64
Flat Tire, Changing a..... 271
Fluids
Automatic Transmission ..221, 222
Brake..... 224
Clutch..... 225
Manual Transmission 223
Power Steering..... 225
Windshield Washer.....220
FM Stereo Radio Reception..... 139
Folding Rear Seat..... 89
Foreign Countries, Driving in..... 305
Four-way Flashers..... 64
Front End, Towing by Emergency Wrecker..... 293
Fuel.....156
Fill Door and Cap..... 156
Gauge..... 57
Octane Requirement..... 156
Oxygenated..... 304
Tank, Filling the..... 156
Fuses, Checking the..... 289

G

Gas Mileage, Improving..... 163
Gasohol..... 304
Gasoline..... 156
Gauge..... 57
Octane Requirement..... 156
Tank, Filling the..... 156
Gas Station Procedures..... 156
Gauges
Engine Coolant Temperature 57
Fuel..... 57
Gearshift Lever Positions
Automatic Transmission..... 174
5-speed Manual Transmission..... 172
Glass Cleaning..... 265
Glove Box..... 79

H

Halogen Headlight Bulbs..... 251
Hazard Warning Flashers..... 64
Headlights..... 60
Aiming..... 249
Automatic Lighting Off..... 61
Daytime Running Lights..... 61
High Beam Indicator..... 54
High Beams, Turning on..... 60
Low Beams, Turning on..... 60
Reminder Chime..... 60
Replacing Halogen Bulbs 251

Turning on..... 60
Head Restraints..... 88
Heating and Cooling..... 106
High Altitude, Starting at..... 172
High-Low Beam Switch 60
HomeLink Universal Transmitter..... 80
Hood, Opening the..... 158
Hot Coolant, Warning about..... 214
Hydraulic Clutch..... 225
Hydroplaning..... 185

I

Identification Number, Vehicle.... 296
If Your Car Has to be Towed..... 293
Ignition
Keys.....69
Switch..... 71
Timing Control System..... 307
Immobilizer System..... 70
Important Safety Precautions 6
Indicator Lights, Instrument Panel.....51
Infant Restraint..... 27
Inflation, Proper Tire 241
Inside Mirror..... 95
Inspection, Tire..... 243
Instrument Panel..... 51
Instrument Panel Brightness..... 61
Interior Cleaning..... 264
Interior Lights..... 103
Introduction..... i

J

Jacking up the Car..... 273
Jack, Tire..... 272
Jump Starting..... 278

K

Keys.....69

L

Label, Certification..... 296
Lane Change, Signaling..... 62
Lap/Shoulder Belts..... 40
Leaking of Exhaust into Car..... 46
Lights
Bulb Replacement..... 251
Indicator..... 51
Parking..... 60
Turn Signal..... 62
LOCK (Ignition Key Position)..... 71
Locks
Anti-theft Steering Column..... 71
Fuel Fill Door.....156
Glove Box..... 79
Power Door..... 73
Trunk..... 78
Low Coolant Level..... 177
Lower Gear, Downshifting to a.... 172
Low Oil Pressure Indicator... 52, 283
Lubricant Specifications Chart.... 298
Luggage..... 166

M

Maintenance..... 193
Owner Maintenance Checks.... 205
Record..... 203 - 204
Required Indicator..... 58
Safety.....194
Schedule..... 198 - 202

CONTINUED